



- BUILDING NOTES**
- 1 BUILD CRUTCH ON TOP VIEW-LEAVE PINNED IN PLACE
 - 2 BUILD SIDES-USE CONTACT CEMENT FOR DOUBLERS-LEAVE 1/2\"/>
 - 3 APPLY CONTACT CEMENT TO OUTSIDE OF CRUTCH & GAP ON SIDES
 - 4 VERY CAREFULLY (BEGIN AT NOSE) PLACE SIDES AGAINST CRUTCH & SMOOTH INTO PLACE
 - 5 INSTALL BOTTOM CROSS BRACES
 - 6 INSTALL FIREWALL-DRILL HOLES FOR RADIAL MOUNT
 - 7 PLANK BOTTOM (REMOVE PINS IN CRUTCH FIRST)
 - 8 LIFT FROM BOARD & GLUE ON 3\"/>
 - 9 PLANK WITH 1/16\"/>

R/C modeler SHOW-OFF

DESIGNED BY CHUCK CUNNINGHAM DRAWN BY DICK KIDD