



WING CONSTRUCTION: BUILD WINGS FLAT. PIN LEADING & TRAILING EDGES IN PLACE & CEMENT ALL NO.1 RIBS IN PLACE EXCEPT FOR CENTER RIB. FIT & INSTALL TIP OUTLINES WITH 7/32" SPACER UNDER THE TIP EDGE & TOP OF TIP PIECE FLUSH WITH TOP OF LEADING EDGE. CEMENT RIB NO.2 IN PLACE WITH A 3/32" SHIM UNDER IT & RIB NO.3 WITH A 5/32" SHIM. TOP SURFACE OF WING IS STRAIGHT. WHEN DRY, SAND OUTLINE TO SHAPE. CUT THRU LEADING & TRAILING EDGES AT CENTER. SHIM 7/32" UNDER BOTH OUTER NO.1 RIBS. FIT CENTER JOINT & CEMENT TOGETHER. CEMENT CENTER RIB IN PLACE.

BEECHCRAFT 17R
 BY-R.V.GROVER & F.T.ROBERTS SPAN 20"
 PUBLISHED-MODEL AIRPLANE NEWS, AUG.1934
 TRACED BY-Dick Eason FEB.11,1962

