



1/8 PLYWOOD BELLCRANK MOUNT

1/4 BALS

3 BELLCRANK

SOLDER NUTS TO BRASS ANGLES & GLUE TO MOUNTS

2 WOOD SCREW

SET BOTH WINGS AT 0° INCIDENCE

.020 THK CELLULOID

1/16 PLY

3/16 SHEET BALS

SOFT BALS BLOCK - CEMENT IN PLACE

1-3/4 DIA. SPINNER

1/8 SHEET BALS

SOFT BALS BLOCK

4 OZ. TANK

1/8 x 1/4 PLANKING

30° UP

30° DOWN

1x1x2 PINE

1/8 SHEET SIDES

1/4 THK SCRAP BALS

1/4 BALS

CUT OUT FOR WING

1/4 BALS

5/8 DIA.

2-56 SCREWS

FOX 59 SHOWN

3/8 SOFT SHEET BALS

HARDWOOD BLOCKS

1/2 SHEET BALS

BALANCE

HARDWOOD FAIRING

1/8 PLYWOOD

2 WOOD SCREWS

1/16 DIA.

1/8 PLYWOOD

2-1/2 DIA.

LOWER WING SHOWN IN BROKEN OUTLINE

1/16 SHEET T.E.

3/16 BALS

W-1

W-1

W-2

W-3

1/16 x 3/16

SOFT BALS

1/2 BALS

W-1

W-1

W-1

W-1

3/16 x 1"

W-1

W-1

W-2

W-3

3/8 DIHEDRAL

COVER CENTER WING WI

PANEL OF LOWER TH 1/16 SH T

SILK

3/16 SQUARE

3/16 SHEET

1/8 WIRE

J-BOLT GEAR IN PLACE

3/32 WIRE