



FULL WING SPAR MAKE 2 OF 1/16" SHEET

AILERON SPAR ONLY ONE

FLAP SPAR PARTS

HOLLOW BLOCK AS INDICATED BY BROKEN LINES. THICKNESS BRINGS BALANCE TO PROPER POINT.

RADIO LOCKER (OUTLINED IN BLACK)

COCKPIT DOOR (OUTLINED IN BLACK)

WING POSITION

WHEEL WELL

GUIDE DETAIL

#12 WIRE LENGTHS BENT AT RIGHT ANGLES ON EACH END, FORCED THRU FORMER AND CEMENTED HEAVILY.

LANDING GEAR TO SCALE  
Axis POSITION SHOWN IS OUT ON DIEDRAL ANGLE.

SCALE OUTLINE & TAB

BUILD TRIM TABS IN-ON BOTH STAB. HALVES AND RUDDER USING SOFT WIRE HINGES.

#12 M.W. DOWELS CEMENTED TO 9 & 10 FOR CHANGEABLE SCALE & FLYING SURFACES.

FRONT REAR  
SHORT SPAR PATTERNS  
2 OF EACH - 1/16" SHEET

SCALE 9/16" = 1'-0"



